




Yukon III Wooden Swing Set Model: 35211



- Owner's Manual
- Frequently Asked Questions
- Assembly Instructions
- Warranty Information

Manufacturer: *Backyard Discovery*
3001 North Rouse
Pittsburg, KS 66762
1-800-856-4445

*Register your new swing set on-line @ www.swingsetonline.com
(you will also find any updates on assembly instructions and
information to order replacement parts)*

Features the  fastening system.

*Save this assembly manual for future reference in the event that
you need to order replacement parts.*

STOP PARE

Missing A Part?

CALL US BEFORE GOING
BACK TO THE STORE!

The store where you made your purchase
does not stock parts for this item.

If you have assembly questions or if you need parts,
whether they are missing or damaged

Call Toll-Free Help Line or visit www.swingsetsonline.com

¡LLÁMENOS ANTES DE REGRESAR A LA TIENDA!

La tienda donde realizó la compra no almacena piezas de este producto.

Si tiene preguntas sobre el ensamblaje o si necesita piezas debido a que
faltan o están dañadas

llame gratis a la línea de ayuda

1-800-856-4445

PLEASE READ THIS BEFORE STARTING ASSEMBLY POR FAVOR LEA ESTAS INSTRUCCIONES ANTES DE COMENZAR EL ENSAMBLAJE

- READ THE ASSEMBLY MANUAL COMPLETELY, PAYING SPECIAL ATTENTION TO THE IMPORTANT TIPS AND SAFETY INFORMATION.
- AFTER YOU HAVE READ THE ASSEMBLY MANUAL, YOU WILL BE ABLE TO DECIDE IF YOU NEED PROFESSIONAL HELP TO COMPLETE THE ASSEMBLY OF THE STRUCTURE.
- SEPARATE AND IDENTIFY ALL PARTS TO MAKE SURE THAT YOU HAVE ALL OF THE PARTS LISTED.
- IF YOU CAN'T FIND ALL OF THE PARTS, CHECK THE PACKING MATERIAL. SMALL PARTS MAY HAVE FALLEN INTO IT DURING SHIPMENT.
- IF YOU HAVE PROBLEMS WITH THE ASSEMBLY OR IF ANY PART IS MISSING OR DAMAGED, PLEASE CALL THE HELP LINE **1-800-856-4445 OR VISIT www.swingsetsonline.com**
- LEA EL MANUAL DE ENSAMBLAJE COMPLETAMENTE, PRESTANDO ESPECIAL ATENCIÓN A LOS CONSEJOS ÚTILES IMPORTANTES Y A LA INFORMACIÓN SOBRE SEGURIDAD.
- DESPUÉS DE QUE HAYA LEÍDO EL MANUAL DE ENSAMBLAJE, PODRÁ DECIDIR SI NECESA AYUDA PROFESIONAL PARA EFECTUAR EL ENSAMBLAJE DE LA ESTRUCTURA.
- SEpare E IDENTIFIQUE TODAS LAS PIEZAS PARA COMPROBAR QUE DISPONE DE TODAS LAS PARTES INDICADAS.
- SI NO PUEDE ENCONTRAR TODAS LAS PIEZAS, REVISE EL MATERIAL DE EMPAQUE. ES POSIBLE QUE ALGUNAS PIEZAS PEQUEÑAS PUEDAN HABERSE CAÍDO ALLÍ DURANTE EL ENVÍO.
- MANTÉNGASE ALEJADO DE LOS NIÑOS MENORES A LA EDAD RECOMENDADA.
- SI TIENE PROBLEMAS CON EL ENSAMBLAJE O SI ALGUNA PIEZA FALTA O ESTÁ DAÑADA, LLAME A LA LÍNEA DE AYUDA AL **1-800-856-4445 O VISITE www.swingsetsonline.com**

PLEASE HAVE THE FOLLOWING INFORMATION WHEN YOU MAKE YOUR CALL:

- 1 – MODEL NUMBER OF THE PRODUCT LOCATED ON THE FRONT OF THE ASSEMBLY MANUAL
- 2 – DESCRIPTION OF THE PART FROM THE PARTS LIST

POR FAVOR TENGA VISIBLE LA SIGUIENTE INFORMACIÓN CUANDO LLAME:

- 1 - NÚMERO DE MODELO DEL PRODUCTO QUE SE ENCUENTRA UBICADO AL FRENTE DEL MANUAL DE ENSAMBLAJE
- 2 - DESCRIPCIÓN DE LA PIEZA QUE SE ENCUENTRA EN LA LISTA DE PIEZAS

Owner's Manual Play Set

Dear Customer:

Please read entire booklet completely before beginning the assembly process.

Equipment is recommended for use by **children 3 to 10 years of age**. Structures are **not intended for public use**. **The Company does not warranty any of its residential structures subjected to commercial use such as: Daycare, Preschool, Nursery School, Recreational Park, or any similar Commercial Application.**



WARNING: This Symbol points out important safety instructions which, if not followed, could endanger the personal safety of yourself and your children and/or damage your property. You **MUST** read and follow all instructions in this manual before attempting to use this playcenter.



WARNING: Children must **NOT** use this playcenter until unit has been completely assembled and inspected by an adult to insure set has been properly installed and anchored.

Please follow all recommendations below. **Failure to do so may result in the warranty being void and/or safety violations that could result in serious injury.** This manual contains helpful information concerning Assembly Preparation, Installation Procedure, and Required Maintenance. Always keep the safety of your children in mind as your play structure is being built and as your children play on the set. Before your children play on the set please review the Operation Instructions with them to help ensure their safety.

PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. KEEP THEM IN A SAFE PLACE WHERE YOU CAN REFER TO THEM AS NEEDED. IN ORDER TO PROVIDE YOU WITH THE MOST EFFICIENT SERVICE, IT IS REQUIRED THAT YOU PROVIDE US WITH THE PART NUMBERS WHEN ORDERING PARTS.

For Your Records:

Please take time and fill out the information below. This information will be needed for warranty issues.

Where Purchased: _____

Date of Purchase: _____



Installation Date: _____

Installed by: _____

Tracking Number: _____

Staple Receipt Here

Sales Receipt	
Store Name	
Main Street	Horizon's USA
100022	BVD Playset
200022	BVD Playhouse
300041	BVD Garden
400015	BVD Outdoor Product
	Total \$555
Thank You For Shopping With Us!	



Tracking Number Reference Label

Tracking ID number on the carton and back of the ID plate are included for tracking purposes associated with warranty claims.

Owner's Manual Play Set

Please refer to the Assembly section of the Assembly Manual for Maximum Fall Height.

Positioning Your Playcenter

1. The Playcenter is designed to be installed on a level surface **by an Adult with an Adult helper**. Place in a flat area of your yard to minimize ground preparation.
2. Choose a level location for the equipment. This can reduce the likelihood of the play set tipping over and loose-fill surfacing material washing away during heavy rains.
3. Place the equipment not less than **6 ft (1.8 m)** from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
4. Provide enough room so that the children can use the equipment safely. For example, for structures with multiple play activities, a slide should not exit in front of a swing.
5. It is a good idea to place your Playcenter in an area that is convenient for adults to watch children at play.
6. Create a site free of obstacles that could cause injuries – such as low overhanging tree branches, overhead wires, tree stumps and/or roots, large rocks, bricks and concrete. Additional suggestions in the Suggested Playground Surfacing Section.
7. Do not build your playset on top of surfacing material.
8. Locate bare metal platforms and slides out of direct sunlight to reduce the likelihood of serious burns. A slide that faces north will receive the least direct sunlight.
9. Separate active and quiet activities from each other. For example, locate sandboxes away from swings or use a guardrail or barrier to separate the sandbox from the movement of the swings.

Suggested Playground Surfacing

- ❑ Do not install home playground equipment over concrete, asphalt, packed earth, grass, carpet, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user.
- ❑ Do not install loose fill surfacing over hard surfaces such as concrete or asphalt.
- ❑ Shredded bark mulch, wood chips, fine sand and fine gravel, are added as shock absorbing materials after assembly. If used properly these materials can absorb some of the impact of a child's fall.
- ❑ All surface material should extend a minimum of 6 feet in all directions around the play area.
- ❑ Do not apply playground surfacing until after the unit is completely constructed. Playset should not be built on top of surfacing.
- ❑ Use containment, such as digging out around the perimeter and/or lining the perimeter with landscape edging.
- ❑ Installations of rubber tiles or poured-in-place surfaces (other than loose-fill materials) generally require a professional and are not "do-it-yourself" projects.
- ❑ Shall use Playground Surfacing Materials (other than loose-fill material) which comply with the safety standard **ASTM F1292** Standard Specification of Impact Attenuation of Surfacing Materials within the Use Zone of Playground Equipment.

Owner's Manual Play Set

The following chart explains the fall height in feet from which a life threatening head injury would not be expected

Critical Heights in feet (m) of Tested Materials

Material	Uncompressed Depth			Compressed Depth
	6" (152mm)	9" (228mm)	12" (304mm)	to 9" (228mm)
Wood Chips	7' (2.13m)	10' (3.05m)	11' (3.35m)	10' (3.05m)
Double-Shredded bark mulch	6' (1.83m)	10' (3.05m)	11' (3.35m)	7' (2.13m)
Engineered Wood Fibers	6' (1.83m)	7' (2.13m)	>12' (3.66m)	6' (1.83m)
Fine Sand	5' (1.52m)	5' (1.52m)	9' (2.74m)	5' (1.52m)
Coarse Sand	5' (1.52m)	5' (1.52m)	6' (1.83m)	4' (1.22m)
Fine Gravel	5' (1.52m)	7' (2.13m)	10' (3.05m)	6' (1.83m)
Medium Gravel	5' (1.52m)	5' (1.52m)	6' (1.83m)	5' (1.52m)
Shredded Tires*	10-12' (3.0-3.6m)	N/A	N/A	N/A

*This data is from tests conducted by independent testing laboratories on a 6-inch depth of uncompressed shredded tire samples produced by four manufacturers. The tests reported critical heights, which varied from 10 feet to greater than 12 feet. It is recommended that persons seeking to install shredded tires as a protective surface request test data from the supplier showing the critical height of the material when it was tested in accordance with ASTM F1292.

Operating Instructions:



NOTE: Your children's safety is our #1 concern. Observing the following statements and warnings reduces the likelihood of serious or fatal injury. Please review these safety rules regularly with your children.

1. This Playcenter is designed for specific number of occupants whose combined weight **should not exceed** a designated weight on the elevated floor or the swing area, the total Unit capacity is outlined in the Basic Setup Dimensions section of instruction manual. The maximum fall height and recommended play area is also available in the Basic Setup Dimensions section of the manual for the specific unit.
2. On-site adult supervision is **required**.
3. Instruct children **not** to walk close to, in front of, behind, or between moving swings or other moving playground equipment.
4. Instruct children to sit in and **never** stand on swings
5. Instruct children **not** to twist the chains and ropes and not to loop them over the top support bar, since this may reduce the strength of the chain or rope.
6. Instruct children **not** to jump from swings or other playground equipment in motion.
7. Instruct children to **not to push** empty seats. The seat may hit them and cause serious injury.
8. Instruct and teach children to sit in the center of the swings with their full weight on the seats.
9. Instruct children **not** to use the equipment in a manner other than intended.
10. Instruct children to **always** go down slides feet first. Never slide head first.
11. Instruct children to **look** before they slide to make sure no one is at the bottom.
12. Instruct children to **never** run up a slide, as this increases their chances of falling.
13. The parents should **dress children appropriately**. (Examples would include the use of well-fitting shoes and the avoidance of ponchos, scarfs, and other loose-fitting clothing that is potentially hazardous while using equipment).
14. Instruct children **not** to climb when the equipment is wet.
15. Instruct children to **never** jump from a fort deck. They should always use the ladder, ramp or slide.
16. Instruct children to **never** crawl or walk across the top of monkey bars.
17. Instruct children to **never** crawl on top of a fort roof.

Owner's Manual Play Set

18. Verify that any suspended climbing ropes, chain, or cable are secured at both ends and that they cannot be looped back on it.
19. Instruct children **not** to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.
20. Instruct children to **never** wrap their legs around swing chain.
21. Instruct children to **never** slide down the swing chain.
22. Instruct children to remove their bike or other sports helmet before playing on playground equipment.

Maintenance Instructions:

At the beginning of each play season:

- Tighten all hardware.
- Lubricate all metallic moving parts per manufacturer's instructions.
- Check all protective coverings on bolts, pipes, edges, and corners. Replace if they are loose, cracked, or missing.
- Check all moving parts including swing seats, ropes, cables, and chains for wear, rust, or other deterioration. Replace as needed.
- Check metal parts for rust. If found, sand and repaint using a non Lead-based paint meeting the requirements of **16 CFR 1303**.
- Check all wood members for deterioration and splinters. Sand down splinters and replace deteriorating wood members.
- Reinstall any plastic parts, such as swing seats or any other items that were removed for the cold season.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

Twice a month during play season:

- Tighten all hardware.
- Check all protective coverings on bolts, pipes, edges, and corners. Replace if they are loose, cracked, or missing.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.
- Once a month during play season.
- Lubricate all metallic moving parts per manufacturer's instructions.
- Check all moving parts including swing seats, ropes, cables, and chains for wear, rust, or other deterioration. Replace as needed.

At the end of each play season or when the temperature drops below 32° F:

- Remove plastic swing seats and other items as specified by the manufacturer and take indoors or do not use.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

Owner's Manual Play Set

Additional Maintenance:

- *Check the swing beam and hardware every two weeks due to wood expansion and contraction. It is particularly important that this procedure be followed at the beginning of each season.*
- *Inspect wood parts monthly. The grain of the wood sometimes will lift in the dry season causing splinters to appear. Light sand may be necessary to maintain a safe playing environment. Treat your playset with stain regularly, to help prevent severe checking/splitting and other weather damage.*
- *A waterbourne transparent stain has been applied to your playset. This is done for color only. Once or twice a year, depending on your climate conditions, you must apply some type of protection (sealant) to the wood of your unit. Prior to the application of sealant, lightly sand any "rough" spots on your playset. **Please note this is a requirement of your warranty.***
- *Assembling and maintaining the playset on a level location is very important. As your children play, your playset will slowly dig its way into the soil, and it is very important that it settles evenly. Make sure the playset is level and true one each year or at the beginning of each play season.*

Disposal Instructions:

When the Playcenter use is no longer desired, it should be disassembled and disposed of in such a way that no unreasonable hazards will exist at the time the unit is discarded.

Third Party Assembly:

Customer may, in their sole discretion, elect to use a third party person or service to assemble this product. Backyard Discovery assumes no responsibility or liability for any charge incurred by the Customer for any assembly services'.

Please see our warranty for more information about damaged and missing part replacement coverage. Backyard Discovery will not reimburse Customer for the price of parts purchased.

Owner's Manual Play Set

APPENDIX A

Information on Playground Surfacing Materials:

The following information is from the **United States Consumer Product Safety Commission's Information Sheet for playground surfacing material**; also see the following website for additional information: www.cpsc.gov/cpscpub/pubs/323.html.

X3. SECTION 4 OF THE CONSUMER PRODUCT SAFETY COMMISSION'S OUTDOOR HOME PLAYGROUND SAFETY HANDBOOK⁹

X3.1 Select Protective Surfacing—One of the most important things you can do to reduce the likelihood of serious head injuries is to install shock-absorbing protective surfacing under and around your play equipment. The protective surfacing should be applied to a depth that is suitable for the equipment height in accordance with ASTM Specification **F 1292**. There are different types of surfacing to choose from; whichever product you select, follow these guidelines:

X3.1.1 *Loose-Fill Materials*:

X3.1.1.1 Maintain a minimum depth of 9 inches of loose-fill materials such as wood mulch/chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for equipment up to 8 feet high; and 9 inches of sand or pea gravel for equipment up to 5 feet high. NOTE: An initial fill level of 12 inches will compress to about a 9-inch depth of surfacing overtime. The surfacing will also compact, displace, and settle, and should be periodically refilled to maintain at least a 9-inch depth.

X3.1.2 Use a minimum of 6 inches of protective surfacing for play equipment less than 4 feet in height. If maintained properly, this should be adequate. (At depths less than 6 inches, the protective material is too easily displaced or compacted.) NOTE: Do not install home playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are generally not adequate protective surfacing. Ground level equipment such as a sandbox, activity wall, playhouse or other equipment that has no elevated play surface – does not need any protective surfacing.

X3.1.3 Use containment, such as digging out around the perimeter and/or lining the perimeter with landscape edging. Don't forget to account for water drainage.

X3.1.3.1 Check and maintain the depth of the loose-fill surfacing material. To maintain the right amount of loose-fill materials, mark the correct level on play equipment support posts. That way you can easily see when to replenish and/or redistribute the surfacing.

X3.1.3.2 **Do not** install loose-fill surfacing over hard surfaces such as concrete or asphalt.

X3.1.4 *Poured-In-Place Surfaces or Pre-Manufactured Rubber Tiles* — You may be interested in using surfacing other than loose-fill materials – like rubber tiles or poured-in-place surfaces.

X3.1.4.1 Installations of these surfaces generally require a professional and are not “do-it-yourself” projects.

X3.1.4.2 Review surface specification before purchasing this type of surfacing. Ask the installer/manufacturer for a report showing that the product has been tested to the following safety standard: ASTM **F 1292** Standard Specification for Impact Attenuation of Surfacing Materials within the Use Zone of Playground Equipment. This report should show the specific height for which the surface is intended to protect against serious head injury. This height should be equal to or greater than the fall height – vertical distance between a designated play surface (elevated surface for standing, sitting, or climbing) and the protective surfacing below – of your play equipment.

X3.1.4.3 Check the protective surfacing frequently for wear.

X3.1.5 *Placement* — Proper placement and maintenance of protective surfacing is essential. Be sure to:

X3.1.5.1 Extend surfacing at least 6 feet from the equipment in all directions.

X3.1.5.2 For to-fro swings, extend protective surfacing in front of and behind the swing to a distance equal to twice the height of the top bar from which the swing is suspended.

⁹ This information has been extracted from the CPSC publications “Playground Surfacing — Technical Information Guide” and “Handbook for Public Playground Safety.” Copies of these reports can be obtained by sending a postcard to the: Office of Public Affairs, U.S. Consumer Product Safety Commission, Washington, D.C., 20207 or call the toll-free hotline: 1-800-638-2772.

Owner's Manual Play Set

The American Society for Testing and Materials takes no position respecting the validity of any parent right asserted in connection with any item mentioned in this standard. Users of this standard are expressly advised that determination of the validity of any such parent rights, and the risk of infringement of such rights, are entirely their own responsibility.

The standard is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either approved or withdrawn. Your comments are invited either for revision of this standard or for additional standards and should be addressed to ASTM Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing you should make your views known to the ASTM Committee on Standards. 100 Barr Harbor Drive, West Conshohocken, PA 19428.

Play Set Assembly Manual FAQs:

1. Does the area for the playset need to be level?

Yes. Backyard Discovery recommends the playset be positioned on a flat level area for maximum safety and durability. The stakes provided should be used to secure it firmly to the ground.

2. What size area is recommended for the playset?

Backyard Discovery recommends at least a 6' (six foot) perimeter around and above the playset for maximum safety.

3. What age range is appropriate for the playsets?

Backyard Discovery playsets are recommended for children ages 3 – 10 years.

4. Is the wood treated with chemicals?

Backyard Discovery uses 100% Chinese Cedar wood which is naturally bug resistant, decay and rot resistant. To help ensure your child's safety, our wood is completely chemical free and we do not use pressure-treated wood. The stain we use is a top coat using a water-based product that is for appearance only.

5. How often should the playset be stained?

Backyard Discovery recommends the playset be stained once each year. A water or oil based stain can be used at the customer's discretion.

6. Why does it seem that my swing set is developing cracks?

Wood is a natural material; no two pieces are exactly alike. Each piece has its own characteristics and personality and reacts differently to climate changes. When any wood product is exposed to the elements, it develops "wood checks". A check is the radial separation of the wood fibers running with the grain of the wood. These are caused by the varying temperature and moisture conditions. A check is not a crack – it does not affect the strength or durability of the wood or structural integrity of the play set.

7. Do Backyard Discovery playsets come with a warranty?

Yes. All Backyard Discovery products carry a 1-year replacement warranty on all parts for manufacturer's defect. Our wood carries a 5 year warranty on rot and decay as well. Please see warranty details for more information.

8. What is the best way to get started assembling the playset?

Backyard Discovery recommends taking all the parts out of the boxes and arranging them by part number before you begin any assembly. This will not only allow faster assembly, but will also identify any parts that may be missing or damaged so they can be replaced before assembly. If parts are missing or need replacement, go to

www.swingsetsonline.com/support.aspx and follow the prompts to order them. Next, read the assembly manual and get the tools ready for the job as recommended in the manual. If the assembly manual is lost or misplaced a new one can be printed from Backyard Discovery's website: www.swingsetsonline.com.

9. The playset seems to rock or sway too much. What's wrong?

Rocking is caused by uneven ground or obstructions such as rocks, roots, etc. under the ground rails. These should be removed and the ground underneath re-leveled to prevent rocking. Also ensure the playset is securely staked to the ground using the stakes provided.

10. The 2"x4" boards do not measure 2"x 4". Why not?

In the U.S. it is common practice to describe lumber dimensions using the rough cut sizes from the sawmill and not the finished dimensions. Retailers, home stores, etc. all use this accepted practice for describing lumber dimensions. However, Backyard Discovery playsets are designed and constructed using the actual dimensions so everything fits properly and remains so during the life of the playset.

11. The end beam is not straight up and down. Why not?

This is normal. Backyard Discovery designs playsets this way to ensure the strongest structure possible. The slight angle adds strength and reduces rocking and twisting.


12. The S-hooks for the swings won't close. What is wrong?

Backyard Discovery recommends placing them on a hard surface such as concrete (don't do this on anything that will dent such as metal or finished wood or glass which will break!). It will take quite a few strokes, but the hooks will close.

For more information and frequently asked questions, please refer to our website at www.swingsetsonline.com.

Tools Required for Installation:

(These are the tools that are generally required for assembly of our swing sets. These tools are not included in the swing set purchase.)




(Level 24")




**(Open End Wrenches
1/2" & 7/16")**



(Nut Drivers 1/2" & 9/16")




(Tape Measure)





**(3/8" Drive Ratchet, 1/2" &
9/16" STD Sockets 1/2" &
9/16" Deep Sockets)**



(Claw Hammer)




(3/8" Cordless Drill or Electric Drill) (3/16", 5/16" & 3/8" Drill Bits)




**(Drill Attachments:
Phillips Head Screw 3/8"
Socket Driver
Torque Head Screw)**



(An Adult w/ an Adult Helper)



**(Phillips & Straight
Blade Screw Drivers)**



(Rubber Mallet - Optional)




(Ladder)

Basic Setup Dimensions

Place the set on level ground, not less than 6 ft [2 m] from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.

Safe Play Zone



Important Assembly Notes

Safe play height: 8' 2 1/4" [2.5 m]
Maximum fall height: 6' 3 5/16" [1.9 m]

- 1) While assembling unit, take time before and after each phase to make sure fort is level. If fort is not level, assembly will be difficult and improper assembly may result. Extra care must be taken to insure the fort is square.
- 2) Pay close attention to the ITEMS NEEDED FOR EACH PHASE. They can be a valuable aid when sorting your wood and hardware. Assembly will be made easier if items are sorted by phase.
- 3) Pay close attention to make sure you are using the correct hardware in the correct phases. Using incorrect hardware may result in improper assembly.
- 4) Whenever a T-nut is used, follow these directions. Place T-nut in pre-drilled hole. Tap in with hammer. Place bolt with washers in the opposite side. Hand tighten to make sure the bolt is in the T-nut. DO NOT over tighten.
- 5) Read the steps of each phase thoroughly. The written steps may include important information not shown in the illustrations.

Parts Identification

Wood Components

(NOT TO SCALE)

(2) E1 - FORT UPRIGHT - W101140
1 3/8" x 3 3/8" x 85 5/8" (36x86x2176)



(2) E2 - FORT UPRIGHT - W101139
1 3/8" x 3 3/8" x 85 5/8" (36x86x2176)




(2) M1 - GROUND BOARD - W101146
5/8" x 3 3/8" x 85 1/2" (16x86x2172)



(1) H80 - GROUND BOARD - W100990
1" x 3 3/8" x 87 3/8" (24x86x2218)



(2) E77 - ANGLE BRACE - W100991
1 3/8" x 3 3/8" x 74 3/8" (36x86x1890)



(5) M2 - FLOOR BOARD - W101143
5/8" x 3 3/8" x 53 3/4" (16x86x1366)



(1) E3 - TARP UPRIGHT - W101141
1 3/8" x 3 3/8" x 54 5/8" (36x86x1386)



(1) G2 - TARP CROSS BRACE - W101142
1" x 5 1/4" x 46 1/2" (24x134x1182)



(1) SB70 - SWING BEAM - W100955
2" x 5 1/4" x 89 1/2" (50x134x2274)



(1) W70 - SWING BEAM SUPPORT - W100956
2" x 3 3/8" x 47 3/8" (50x86x1204)



(4) P1 - PICNIC TABLE UPRIGHT - W101155
1 3/8" x 1 3/8" x 46 1/4" (36x36x1175)



(2) P3 - PICNIC TABLE SUPPORT - W101157
1 3/8" x 1 3/8" x 13 7/8" (36x36x354)



(6) M71 - ROCK BOARD - W100022
5/8" x 3 3/8" x 20 1/4" (16x86x514)



(1) N2 - SWING BLOCK SAFETY RAIL - W101149
5/8" x 2 3/8" x 66 1/8" (16x60x1680)



Parts Identification


Wood Components

(NOT TO SCALE)

(8) M4 - PICNIC TABLE BOARD - W101151
5/8"x3 3/8"x17 3/8" (16x86x442)




(1) H2 - TARP UPRIGHT - W101144
1"x3 3/8"x20 1/4" (24x86x514)



(2) M5 - LOWER WALL RAIL - W101154
5/8"x3 3/8"x13 1/2" (16x86x344)




(1) H79 - END SUPPORT - W100992
1"x3 1/2"x42" (24x86x1072)



(2) H1 - FLOOR BRACE - W101147
1"x3 3/8"x54 3/4" (24x86x1392)




(4) M3 - WALL SLAT - W101148
5/8"x3 3/8"x38" (16x86x964)




(2) K1 - TARP END CAP - W101145
5/8"x5 1/4"x22 1/4" (16x134x565)




(1) G1 - TARP SWING BEAM CROSS BRACE - W101153
1"x5 1/4"x46 1/2" (24x134x1182)




(1) M77 - SLIDE BRACE - W100544
5/8"x3 3/8"x17 1/4" (16x86x438)




(2) M78 - CENTER SLIDE BRACE - W100545
5/8"x3 3/8"x17 1/4" (16x86x438)



(2) P2 - PICNIC TABLE SEAT SUPPORT - W101156
1 3/8"x1 3/8"x30" (36x36x762)



(3) N1 - FLOOR SUPPORT - W101152
5/8"x2 3/8"x15 1/2" (16x60x394)




(4) M72 - ROCK WALL SLAT - W100023
5/8"x3 3/8"x20 1/4" (16x86x514)



Parts Identification


Hardware




(4) AJ - BOLT HEX 5/16x1 1/4 - H100042




(2) AN - BOLT HEX 5/16x2-3/4 - H100047




(2) Z - LAG SCREW WH 5/16x2 - H100027




(6) CM - BOLT WH 5/16x1/2 - H100115




(10) H - BOLT WH 5/16x1 1/2 - H100010



(4) J - BOLT WH 5/16x1 3/4 - H100011



(20) K - BOLT WH 5/16x2 - H100012



(2) L - BOLT WH 5/16x2 1/4 - H100013




(7) M - BOLT WH 5/16x2 1/2 - H100014






(2) P - BOLT WH 5/16x3 - H100016




(1) KA - BOLT WH 5/16x4 1/2 - H100021




(6) BG - T-NUT 5/16 - H100074




(6) BF - T-NUT 3/8 - H100073




(47) AC - WASHER LOCK EXT 8x19 - H100030





(53) AD - WASHER LOCK EXT 12x19 - H100031





(6) A - BOLT FA 3/8x1 1/2 - H100001



(9) BC - SCREW PWH 8x3/4 - H100070



(6) B - NUT BARREL WH 5/16x5/8 - H100004




(45) D - NUT BARREL WH 5/16x7/8 - H100005

Parts Identification


Hardware



(14) CH - SCREW TAPPING 14x1-1/2 - H100109



(4) BJ - SCREW TAPPING 14x1 - H100080



(12) BL - SCREW TAPPING 14x3/4 - H100083



(24) BW - SCREW PFH 8x3 - H100092




(50) BV - SCREW PFH 8x2 1/4 - H100091



(4) BS - SCREW PFH 8x1 3/4 - H100089




(35) BP - SCREW PFH 8x1 1/2 - H100086




(20) BQ - SCREW PFH 8x1 1/4 - H100087



(36) BR - SCREW PFH 8x1 1/8 - H100088




(6) CB - WASHER SAFETY 17x30 - H100103




(16) CD - WASHER FLAT 8x27 - H100105



(6) BZ - SWING HANGER QUICK LINK - H100099




(8) CG - WASHER LOCK INT 8x15 - H100108




(10) CE - WASHER FLAT 9x18 - H100106



(2) T-40 Torx Wrench - A100041



(10) CJ - NUT LOCK 5/16 - H100110







(2) T-40 Torx Bit - A100042

Parts Identification

Accessories

(NOT TO SCALE)




4 Ft Swing Beam

Phase 1

Phase Notes

- Assemble with hardware as shown.




QTY	DESCRIPTION
4	WASHER FLAT 8x27
2	NUT LOCK 5/16
2	L BRACKET 66x66x127 BLUE
2	BOLT HEX 5/16x2-3/4
1	SWING BEAM
2	NUT BARREL WH 5/16x7/8
2	WASHER LOCK EXT 12x19
2	TRIANGLE PLATE 105 5 HOLE
2	BOLT WH 5/16x1-3/4

4 Ft Swing Beam

Phase 2

Phase Notes

- Assemble with hardware as shown.




4 Ft Swing Beam

Phase 3

Phase Notes

- Assemble with hardware as shown.




4 Ft Swing Beam

Phase 4

Phase Notes

- Assemble with hardware as shown.



Fort Assembly

Phase 1

Parts needed:


- (2) E1 - FORT UPRIGHT - W101140
- (2) E2 - FPRT UPRIGHT - W101139
- (2) H1 - FLOOR BRACE - W101147
- (2) M1 - GROUND BOARD - W101146

Hardware needed:

- (12) D - NUT BARREL WH 5/16x7/8 - H100005
- (12) AD - WASHER LOCK EXT 12x19 - H100031
- (12) AC - WASHER LOCK EXT 8x19 - H100030
- (4) H - BOLT WH 5/16x1-1/2 - H100010
- (8) K - BOLT WH 5/16x2 - H100012

Phase Notes

- Assemble with hardware as shown.
- For ease during assembly, assemble uprights flat on the ground.



Step 1: Attach 'H1' Floor Brace to the inside of 'E1' & 'E2' Fort Uprights using hardware 'D', 'AD', 'AC' and 'K', as shown.



Note: It is vital that the fort be level before and after each phase of assembly.

Step 2: Attach 'M1' Ground Board to the outside of 'E1' & 'E2' Fort Uprights using hardware 'D', 'AD', 'AC' and 'H', as shown.

Fort Assembly

Phase 2

Parts needed:

- (2) M72 - ROCK WALL SLAT - W100023

Hardware needed:


- (8) BV - SCREW PFH 8x2-1/4 - H100091

Phase Notes

- **Assemble with hardware as shown.**



Note: It is vital that the fort be level before and after each phase of assembly.



Step 1: Attach 'M72' Rock Wall Slat to the edges of 'E1' & 'E2' Fort Uprights using hardware 'BV', as shown.

Fort Assembly

Phase 3

Parts needed:


- (5) M2 - FLOOR BOARD - W101143
- (3) N1 - FLOOR SUPPORT - W101152

Hardware needed:



- (30) BR - SCREW PFH 8x1-1/8 - H100088
- (6) GW - L BRACKET BLUE 54 x 67 - H100158
- (12) BL - SCREW TAPPING 14x3/4 - H100083

Phase Notes

- Assemble with hardware as shown.



Step 1: Place Floor Supports 'N1' on Floor Boards 'M2' approximately 3 11/16" from both edges of 'M2' boards and attach the remaining 'N1' support, as shown. Attach N1 supports to 'M2' boards using screws 'BR', as shown. Finally, secure L-Brackets 'GW' to 'N1' supports using screws 'BL', as shown.



Step 2: Attach Floor Panel to Floor Brace 'H1' using screws 'BL', as shown.



Note: It is vital that the fort be level before and after each phase of assembly.

Fort Assembly

Phase 4

Parts needed:

- (3) **GE - MONKEY BAR RUNG - A100151**

Hardware needed:


- (6) **CH - SCREW TAPPING 14x1-1/2 - H100109**

Phase Notes

- **Assemble with hardware as shown.**



Note: It is vital that the fort be level before and after each phase of assembly.



Fort Assembly

Phase 5

Parts needed:


- (6) M71 - ROCK BOARD - W100022
- (1) M72 - ROCKWALL SLAT - W100023
- (3) GX - CLIMBING ROCK BLUE SMALL - A100159
- (3) GY - CLIMBING ROCK YELLOW SMALL - A100160

Hardware needed:

- (6) BF - T-NUT 3/8 - H100073
- (6) A - BOLT FA 3/8x1-1/2 - H100001
- (6) BR - SCREW TAPPING 8x1-1/8 - H100088
- (28) BV - SCREW PFH 8x2-1/4 - H100091

Phase Notes

- Assemble with hardware as shown.





Step 1: Gather the (6) Rockwall Boards 'M71' and hammer 3/8" T-nuts 'BF' into large hole on each board.



Note: It is vital that the fort be level before and after each phase of assembly.

Step 4: Attach Rockwall Rocks 'GY' and 'GX' to Rockwall Boards 'M71' using bolts 'A' through rock and board and into previously placed T-nut, and with screw 'BR', as shown.



Step 2: Attach first Rockwall Board 'M71' by placing the board flush with the bottom of the fort floor where shown and attaching to Uprights 'E2' with screws 'BV', as shown. (The T-nut must go to the inside of the fort.) Repeat process for remaining (5) Rockwall boards making sure to space boards 2 7/8" apart. Boards must be placed so the rock holes alternate from top to bottom.

Step 3: Attach Rockwall Board 'M72' to fort equally spaced below last Rockwall Board 'M71', as shown.

Fort Assembly

Phase 6

Parts needed:


- (4) EA - YELLOW HAND GRIP - W100043

Phase Notes



- Assemble with hardware as shown.

Hardware needed:

- (8) CE - WASHER FLAT 9x18 - H100106
- (8) CG - WASHER LOCK INT 8x15 - H100108
- (8) CH - SCREW TAPPING 14x1-1/2 - H100109



To prevent board splitting, you must pre-drill each board before attaching with a 1/8" drill bit.



Step 1: Attach (1) Hand Grip 'EA' to the side of each upright and ladder rail with screw 'CH' and washers 'CG' & 'CE', as shown.

Fort Assembly

Phase 7

Parts needed:


- (1) G1 - TARP SWING BEAM CROSS BRACE - W101153
- (1) G2 - TARP CROSS BRACE - W101142
- (1) H2 - TARP UPRIGHT - W101144
- (2) K1 - TARP END CAP - W101145
- (1) M72 - ROCK WALL SLAT - W100023
- (1) E3 - TARP UPRIGHT - W101141

Hardware needed:

- (2) D - NUT BARREL WH 5/16x7/8 - H100005
- (2) AD - WASHER LOCK EXT 12x19 - H100031
- (4) AC - WASHER LOCK EXT 8x19 - H100030
- (2) H - BOLT WH 5/16x1-1/2 - H100010
- (2) L - BOLT WH 5/16x2-1/4 - H100013
- (2) BG - T-NUT 5/16 - H100074
- (12) BV - SCREW PFH 8x2-1/4 - H100091


Phase Notes

- Assemble with hardware as shown.



These two holes in 'G1' & 'G2' boards are not centered.
Correct installation requires the holes to be installed as shown.

Step 3: Attach Rock Wall Slat 'M72' to top of Tarp Uprights 'H2' & 'E3' using screws 'BV', as shown.



Step 1: Attach Tarp Uprights 'H2' & 'E3' to Tarp Swing Beam Cross Brace 'G1' & Tarp Cross Brace 'G2' using Safe-T-Fuse hardware, as shown.

Use a 10mm drill bit to open holes if hardware does not fit into holes.

Step 2: Attach Tarp End Caps 'K1' to ends of Cross Braces 'G1' & 'G2' using screws 'BV', as shown.



Fort Assembly

Phase 8

Parts needed:

- (2) GL - PLATE 3 HOLE BLUE - A100149


Phase Notes

- Assemble with hardware as shown.
- The Roof Assembly attaches differently on back of the Fort then it does on the front.



Note: It is vital that the fort be level before and after each phase of assembly.



Step 2: Attach Roof Assembly to back of fort by placing Bolt 'K' and Washer 'AC' through the Cross Beam 'G1' and the top hole on Plate 'GL', then through the upright and secure using hardware 'AD' and 'D', as shown.




Step 3: Finish securing the Fort Plate 'GL' to the uprights and cross beam using Screws 'BJ' through open holes, as shown.

These two holes not centered. Correct installation requires the holes to be installed as shown.

Step 1: Attach Roof Assembly to front uprights of fort using hardware 'D', 'AD', 'AC' and 'K', as shown.



Step 4: Attach 'E3' roof upright to 'H1' floor brace using Screws 'BV', as shown.



Hardware needed:

- (4) D - NUT BARREL WH 5/16x7/8 - H100005
- (4) AD - WASHER LOCK EXT 12x19 - H100031
- (4) AC - WASHER LOCK EXT 8x19 - H100030
- (4) BJ - SCREW TAPPING 14x1 - H100080
- (4) K - BOLT WH 5/16x2 - H100012
- (2) BV - SCREW PFH 8x2-1/4 - H100091

Fort Assembly

Phase 9

Parts needed:

- (4) M3 - WALL SLAT - W101148
- (2) M5 - LOWER WALL RAIL - W101154
- (1) GP - ROOF TARP - A100150

Hardware needed:



- (9) BC - SCREW PWH 8x3/4 - H100070
- (20) BQ - SCREW PFH 8x1-1/4 - H100087

Phase Notes


- Assemble with hardware as shown.

Step 1: Attach one end of each Wall Slats 'M3' to the inside of the Corss Beams 'G1' & 'G2' with Screws 'BQ' and attach the other end to the outside of Floor Supports 'H1' with Screws 'BQ', as shown.

Step 2: Attach top end of each Lower Wall Rails 'M5' to the inside of wall slats 'M3' with Screws 'BQ', as shown. Make sure the diagonal corners of 'M5' rails are flush with the outside edge of 'M3' wall slats.



Step 3: Drape Tarp 'GP' over support 'M72' and Tarp End Caps 'K1'. Attach one side of tarp to inside of 'K1' with (3) Screws 'BC'. Pull other side of tarp tight and attach to the inside of other 'K1' end cap using (3) Screws 'BC'. Finally, secure tarp to 'M72' support with (3) Screws 'BC', as shown.



The wall slats should be spaced 2 3/4" away from uprights.

Fort Assembly

Phase 10

Parts needed:

- (4) P1 - PICNIC TABLE UPRIGHT - W101155
- (2) P2 - PICNIC TABLE SEAT SUPPORT - W101156
- (2) P3 - PICNIC TABLE SUPPORT - A100157
- (1) N2 - SWING BLOCK SAFETY RAIL - W101149



Hardware needed:

- (10) D - NUT BARREL WH 5/16x7/8 - H100005
- (10) AD - WASHER LOCK EXT12x19 - H100031
- (10) AC - WASHER LOCK EXT8x19 - H100030
- (6) M - BOLT WH 5/16x2-1/2 - H100014
- (2) H - BOLT WH 5/16x1-1/2 - H100010
- (2) P - BOLT WH 5/16x3 - H100016

Phase Notes

- Assemble with hardware as shown.

Step 1: Assemble the (2) Picnic Table Frames by attaching Picnic Table Supports 'P3', Swing Block Safety Rail 'N2' and Picnic Table Seat Supports 'P2' to Picnic Table Uprights 'P1' using "Safe-T-Fuse" hardware, as shown.



Step 2: Attach Frame Support to inside of each Ground Beam 'M1' using "Safe-T-Fuse" hardware, as shown.

Fort Assembly

Phase 11

Parts needed:


- (8) M4 - PICNIC TABLE BOARD - W101151

Phase Notes

- Assemble with hardware as shown.

Hardware needed:



- (6) D - NUT BARREL WH 5/16x7/8 - H100005
- (6) AD - WASHER LOCK EXT 12x19 - H100031
- (6) AC - WASHER LOCK EXT 8x19 - H100030
- (4) K - BOLT WH 5/16x2 - H100012
- (2) H - BOLT WH 5/16x1-1/2 - H100010
- (32) BP - SCREW PFH 8x1-1/2 - H100086
- (4) BS - SCREW PFH 8x1-3/4 - H100089



Note: It is vital that the fort be level before and after each phase of assembly.

Step 1: Attach back side Picnic Table Frame to 'H1' Floor Support using "Safe-T-Fuse" hardware. Attach 'N2' Swing Block Safety Rail to the outside of 'E1' & 'E2' Left Fort Upright Assembly with screws 'BS', as shown.

Step 2: Attach front side Picnic Table Frame to 'H1' Floor Support and 'M1' Ground Floor using "Safe-T-Fuse" hardware, as shown.



Step 3: Attach the Picnic Table Boards 'M4' to the frame with Screws 'BP', as shown. (2) Boards 'M4' will be used for each seat and (4) Boards will be used for the table top.

Swing Beam Attachment

Phase 1

Parts needed:


- (1) SWING BEAM ASSEMBLY
- (1) HC - BACKYARD DISCOVERY ID TAG - A100164

Phase Notes

- Assemble with hardware as shown.


Hardware needed:

- (4) BG - T-NUT 5/16 - H100074
- (4) BX - WASHER SPLIT 5/16 - H100095
- (4) CD - WASHER FLAT 8x27 - H100105
- (4) AJ - BOLT HEX 5/16x1-1/4 - H100042
- (4) CY - SCREW PFH 8x5/8 - H100128



Step 1: Attach the Swing Beam Assembly to 'G1' Tarp Swing Cross Beam using Bolts 'AJ', Washer 'BX' & Washer 'CD' through the angle brackets & 'G1' cross beam and into T-Nut 'BG' that will need to be hammered in the holes on the backside of 'G1', as shown.

Step 2: Attach Backyard Discovery ID Tag 'HC' on Swing Beam 'SB70' using Screws 'CY', as shown.



Slide Attachment

Phase 1

Parts needed:

- (1) SLIDE ASSEMBLY

Phase Notes


- Assemble with hardware as shown.

Hardware needed:



- (3) B - NUT BARREL WH 5/16x5/8 - H100004
- (3) AD - WASHER LOCK EXT 12x19 - H100031
- (3) CM - BOLT WH 5/16x1/2 - H100115

Step 1: Center the wave slide assembly in the opening opposite the swing beam assembly, as shown.

Step 2: Using a drill with a 3/8" bit, drill a hole through the holes on the slide and through the fort floor.



Step 3: Attach the Slide Assembly to the fort floor using the Safe-T-Fuse hardware, as shown.



SLIDE DRILLING PATTERN

Anchoring Instructions

Phase 1

Parts needed:

- (6) **KD - PLASTIC GROUND STAKE BROWN - A100179**
- (2) **FB - SWING SEAT ASSEMBLY - A100170**
- (1) **KF - PLASTIC TRAPEZE BAR ASSEMBLY YELLOW - A100109**

Hardware needed:

- (6) **BV - SCREW PFH 8x2-1/4 - H100091**



Phase Notes

- **Assemble with hardware as shown.**
- **Install the screw into the upright so that the tip of the screw does not stick through. Make sure you have enough wood to accommodate the screw before installing.**
- **FAILURE TO USE STAKES CAN VOID WARRANTY & CAUSE INJURY!**


Step 1: Drive Stakes 'KD' into the ground against boards where shown and attach with Screws 'BV', as shown.

Step 2: Attach Swing Seat Assembly 'FB' to swing beam.

Step 3: Attach Trapeze Bar Assembly 'KF' to swing beam using pre-assembled quick clips installed on the swing beam.



Final Step: Double check and make sure every bolt, screw and nut is tight. Make sure every board is secure. Make sure the fort is level and enjoy your swing set.



Limited Warranty

This Limited Warranty by Backyard Discovery applies to products manufactured under the Backyard Discovery brand or its other brands including but not limited to Backyard Botanical, Adventure Playsets, and Leisure Time Products.

Backyard Discovery warrants that this product is free from defect in materials and workmanship for a period of one (1) year from the original date of purchase. This one (1) year warranty covers all parts including wood, hardware, and accessories. All wood carries a five (5) year pro-rated warranty against rot and decay. Refer to the schedule below for charges associated with replacement of parts under this Limited Warranty. In addition, Backyard Discovery will replace any parts within the first 30 days from date of purchase found to be missing from or damaged in the original packaging.

This warranty applies to the original owner and registrant and is **non-transferable**. Regular maintenance is required to assure maximum life and performance of this product and failure by the owner to maintain the product according to the maintenance requirements may void this warranty. Maintenance guidelines are provided in the Owner's Manual.

This Limited Warranty does not cover:

- Labor for any inspection
- Labor for replacement of any defective item(s)
- Incidental or consequential damages
- Cosmetic defects which do not affect performance or integrity of a part or the entire product
- Vandalism, improper use, failure due to loading or use beyond the capacities stated in the applicable Assembly Manual.
- Acts of nature including but not limited to wind, storms, hail, floods, excessive water exposure
- Improper installation including but not limited to installation on uneven, unlevel, or soft ground
- Minor twisting, warping, checking, or any other natural occurring properties of wood that do not affect performance or integrity

Backyard Discovery products have been designed for safety and quality. Any modifications made to the original product could damage the structural integrity of the unit leading to failure and possible injury. Modification voids any and all warranties and Backyard Discovery assumes no liability for any modified products or consequences resulting from failure of a modified product.

This product is warranted for **RESIDENTIAL USE ONLY**. Under no circumstance should a Backyard Discovery product be used in public settings. Such use may lead to product failure and potential injury. Any and all public use will void this warranty. Backyard Discovery disclaims all other representations and warranties of any kind, express or implied.

This Warranty gives you specific legal rights. You may have other rights as well which vary from state to state or province to province. This warranty excludes all consequential damages, however, some states do not allow the limitation or exclusion of consequential damages and therefore this limitation may not apply to you.

Pro Rated Part Replacement Schedule

Product Age

All Parts

0-30 days from date of purchase
31 days to 1 year

Customer Pays

\$0 and free shipping
\$0 + S&H

Wood Rot and Decay Only

1 year
2 years
3 years
4 years
5 years
Over 5 years

\$0 and free shipping
20% + S&H
40% + S&H
60% + S&H
80% + S&H
100% + S&H